www.fs2crew.com

FS2CREW MODE: < between brackets >

THIS DOCUMENT ONLY CONTAINS THE CAPTAIN (PF) FLOWS

WHITE/BLUE - CALL FOR CHECKLIST FS2CREW FLOW INSTRUCTION RED TEXT: PHRASE SPOKEN BY YOU ** SEE NOTE FOR ADDITIONAL

DIALOGUE AND INFORMATION * TRIGGER PHRASE

COUNT DOWN TIMER IS SET IN THE DIALO	DGE BOX	DEPARTURE BRIEFING	
		ARE YOU READY FOR THE DEPARTURE B	RIEF?
PRE-START PROCEDURE	<pre (b)="" start=""></pre>	ANY QUESTIONS ?	
PARKING BRAKE	ON		
BATTERY SWITCH	ON AND LOCK	PRE-START PROCEDURE	+5 MINUTES
FIRE LOOP TEST	PERFORM	FMS PERF PAGE	ENTER ZFW
EXTERNAL POWER	CONNECT AND ON BUSES	FLAP SETTING WINDOW	SET
IF NO EXT POWER	USE THE APU	CG WINDOW	SET
AFTER STARTING APU		STABILIZER TRIM	SET
APU AIR SWITCH	ON (CHECK AIR PRESS CTR DUCT)	APU	CONFIRM ON & APU AIR SELECTED
RIGHT PNEU-X-FEED	OPEN		
RIGHT AIR COND SUPPY	AUTO	PRE-START PROCEDURE	+4 MINUTES
IF START PUMP IS ON	SET RIGHT AFT FUEL PUMP TO ON	SEAT BELT SIGN	ON
	SET THE START PUMP TO OFF		
POS/STROBE	BOTH	PRE-START CHECK ABOVE THE LINE	
WING/NACL	ON	PREVIOUSLY COMPLETED SILENTLY BY FO	
ONLY AFTER APU/EXT PWR ESTABLISHED	, PRESS "START" ON FS2CREW		
	CONFIGURATION PANEL	PRE-START CHECKLIST BELOW THE LINE	<pre (b)="" start=""></pre>
STANDBY ATTITUDE INDICATOR	CAGE	COVERS AND PINS	REMOVED
EMERGENCY LIGHT TEST	PEFORM WITH FA	AIRCRAFT LOG & DOCUMENTS	CHECKED ON BOARD
ARRIVAL ELEVATION DATA	SET IN PRESSURIZATION PANEL	ALTIMETERS	QNH/SET/CHECKED
FLIGHT DATA RECORDER PANEL	SETUP	FUEL/OIL/HYD QUANTITY	CHECKED
EXTERNAL WALK AROUND	PERFORM	ZERO FUEL WEIGHT	SET
FMS AND FLIGHT CONTROL PANEL	SETUP	TRP	TAKEOFF / TAKEOFF FLEX
BANK ANGLE LIMIT	ROTATE TO 15°	STABILIZER	SET **
AFTER FO PRE-FLIGHT PROC COMPLETE	* TO RIGHT OF <pre-start(b)></pre-start(b)>	FLAPS TAKEOFF SELECTOR	STOWED
SPEED BUGS	SET ACCORDING TO SPEED BOOK	SPEED BUGS	SET

<before check="" start=""></before>	+1 MIN AFTER LOAD SHEET ARRIVES
PARKING BRAKES	SET / RELEASED
DOORS	CLOSED**
START-UP & PUSHBACK CLEARANCE	APPROVED
PNEUM X-FEED VALVE LEVERS	OPEN
AUX & TRANS HYD PUMPS	AS REQUIRED
ANTI COLLISION LIGHT	ON
AIR COND SUPPLY	OFF
FUEL PUMPS	ON
GALLEY POWER	OFF
IGNITION	A OR B
PNEUM PRESS	CHECKED

PUSHE	ВАСК
SPEAK	COCKPIT TO GROUND
SPEAK ONE OF	We've been cleared for pushback and engine start**
SPEAK	BRAKES RELEASED
SPEAK	BRAKES SET
SPEAK	GOOD BYE**

		1 67 11
ENGINE START	<s.crw eng="" start=""></s.crw>	
PNEUMATIC PRESSURE	CHECK ABOVE 36 PSI	
CALL	START RIGHT ENGINE	WHE
TIMER	START	LAND
FO CALLS "FUEL ON"	MOVE FUEL LEVEL ON, TAKE TIME	WHE
ANNOUNCE	FUEL ON	TOG
RIGHT ENGINE STABILIZED	ENGINE ANTI ICE ON (IF REQUIRED)	FLICK
TIMER	RESET	
CALL	START LEFT ENGINE	
TIMER	AS ABOVE	FUEL
FO CALLS "FUEL ON"	MOVE FUEL LEVEL ON, TAKE TIME	FLAP
ANNOUNCE (AND REPEAT ABOVE)	FUEL ON	EPR E
TO ABORT THE START CALL	ABORT START	ТАКЕ
		то в
<after engine="" start=""></after>		ATC /
GALLEY POWER	ON	FMS

CHECK IN LIMITS

AUTO

ELECTRICAL LOADS (AC and DC)

AIR CONDITIONING SUPPLY SWITCHES

<aft eng="" start=""></aft>
OFF
CHECKED
AUTO
ON
OFF/ENG ANTI ICE ON/BOTH ON
CLOSED / OPEN
ACTIONS AND DIALOGUE BELOW
LEFTSPOILER DEPLOYED
RIGHTSPOILER DEPLOYED
ELEVATOR POWER ON
ELEVATOR POWER NOT DISPLAYED
PEDALS
FLIGHT CONTROLS CHECK COMPLETED
CHECKED / HI /ON**
CHECKED
CHECKED
REMOVED
RECEIVED
SET
WE ARE CLEAR ON THE LEFT

WHEN READY TO TAXI CALL	WE ARE CLEAR ON THE LEFT
LANDING LIGHTS/NOSE LIGHT	EXT OFF/DIM
WHEN AREA CLEAR	CALL FOR CHECKLIST
TOGA BUTTON	PRESS (FMA TAKEOFF/TAKEOFF)
FLICK THROTTLES MAX/MIN	CHECK FOR NO TAKEOFF WARNING
<taxi check=""></taxi>	<taxi></taxi>

FUEL HEAT	NOT REQUIRED / ON / OFF
FLAPS AND SLATS	DEGREES TAKEOFF**
EPR BUGS AND TRP	SET AND CHECKED
TAKEOFF SPEEDS	NO CHANGES, VERIFIED**
TO BRIEFING	PERFORMED
ATC / DFGS / NAVAIDS	SET AND CHECKED
FMS	PRE-FLIGHT COMPLETED
APU AIR / MASTER SW	BOTH OFF / AIR OFF**
BRAKE TEMP AND PRESSURE	СНЕСКЕД

<line up=""></line>		REJECTED TAKEOFF PROCEDURE	<reject></reject>
ANNOUNCE	CABIN CREW SEATS FOR TAKEOFF*	TO INITIATE RTO	BRING THROTTLES TO IDLE
WEATHER RADAR	ON	IN TAKEOFF ROLL MODESPEAK	REJECT
LANDING LIGHTS	EXT ON	THROTTLES	APPLY MAX REVERSE & MAX BRAKIN
		SPEEDBRAKES	ENSURE UP (PNF WILL ADVISE IF NO
<lineup check=""></lineup>		SUBSEQUENT CALLS	SAMES AS NORMAL ROLL OUT
CABIN	SECURED	ONCE STOPPED MAKE PA	CABIN CREW AND PASSENGERS
WINDOWS	LEFT SIDE CLOSED		REMAIN SEATED
ANNUNCIATOR PANEL	CHECKED	BELOW 30 KNOTS	RETRACT SPEEDBRAKE
IGNITION	SET TO A / SET TO B**	MODE CHANGE TO AFTER LANDING	PNF PERFORM AFTER LANDING FLO
AIR COND SUPPLY	AUTO / MANUAL	TAXI BACK TO TRY AGAIN	CYCLE MODE TO RIGHT ONLY
TRANSPONDER	TARA		IN THE FS2CREW PANEL
TAKEOFF CLEARANCE	RECEIVED**		
WHEN CLEARED FOR TAKEOFF	<ready></ready>	<climb check=""></climb>	
NOSE LIGHT	BRIGHT	GEAR	UP
SEATBELT SWITCH	CYCLE	FLAPS / SLATS	UP / RETRACTED
ASK FO	READY*	AUTOSPOILERS / ABS	OFF DISARMED**
FO ANSWERS "YES"	START TIMING**	FLAPS TO SELECTOR	STOW
		TRANS & AUX HYD PUMPS	OFF
TAKEOFF	<t -="" fo="" o="" roll=""></t>	PRESSURIZATION	CHECKED
ANNOUNCE	TAKEOFF	IGNITIONJ	SET
THROTTLES	ADVANCE 1.40 EPR	FUEL PUMPS	AS REQUIRED
AUTOTHROTTLE	ON	SEATBELTS	ON / OFF / AUTO**
<initial climb=""></initial>		WHEN CLEARED TO A FLIGHT LEVEL	
POSITIVE RATE OF CLIMB	GEAR UP	SPEAK	TRANSITION* PASSING
LANDING LIGHTS/NOSE LIGHTS	RET OFF/OFF		FLIGHT LEVEL XX NOW*
AT 400 FEET	ARM NAVIGATION/		
	ENGAGE HEADING SELECT	PASSING 10,000 / FL100	
AT 1500 FEET	SELECT CLIMB POWER	CROSS CHECK ALTIMITERS	PASSING
AT 3000 FEET	ENGAGE VNAV/ENGAGE IAS		FLIGHT LEVEL 100 NOW*
FLAPS (DIRECT TO FULL UP)	FLAPS UP		
SLATS RETRACTION SPEAK	SLATS RETRACT		
ONCE SLATS RETRACTED	CALL FOR CLIMB CHECK		
ABOVE MIN CLEAN SPEED	ROTATE BANK LIMIT TO 25°		

CRUISE		<approach check=""></approach>	
FS2CREW - SET HARD MUTE	PREVENT UNWANTED COMMANDS	NAVIGATION	SET
PA ANNOUNCEMENTS	IF DESIRED (ON YOUR OWN)		
POWER ON TRP	SET TO CRUISE (CR)	LANDING (ON FINAL)	<final></final>
		ASK PNF TO SET RADIOS	SET ILS ON NAV 2
JUST PRIOR TO TOP OF DESCENT			SET LOCALISER ON NAV 2
TRANSPONDER	BELOW		SET VOR ON NAV 2
APPROACH BRIEF	ARE YOU READY FOR THE	CALL	LOCALISER CAPTURE
	APPROACH BRIEF	CALL	GLIDESLOPE CAPTURE
AUTOLAND	ANY QUESTIONS (THEN YES/NO)	EXTEND FLAPS ON SCHEDULE	SLATS EXTEND/FLAPS 15 ETC
CONFIRM DECISION ALTITUDE	FS2CREW CONFIG PANEL	AFTER FINAL LANDING FLAP SELECTED	CALL "FINAL CHECK"
	SET DH BUG CAPTAINS ALTIMETER	PASSING OUTER MARKER/4DME	LANDING LIGHTS EXT ON/DIM
CALL	DESCENT CHECK	BANK ANGLE LIMIT	ROTATE TO 15°
		AFTER LAND CLEARANCE RECEIVED	NOSE LANDING LIGHT BRIGHT
DESCENT CHECK	<decent></decent>	<final check=""></final>	
PRESSURIZATION	SET	GEAR	DOWN
FUEL PUMPS	SET	IGNITION	SET TO A / SET TO B
HYDRAULIC PUMPS	HI / ON	AUTOSPOILERS & AUTOBRAKES	ARMED
FUEL QUANTITY	CHECKED	FLAPS & SLATS	FLAPS LAND
APPROACH BRIEFING	PERFORMED	LANDING CLEARANCE	RECEIVED (TO GO, TO COME)
LANDING DATA	SET	ONCE RECEIVED	LANDING CLEARANCE RECEIVED
ALTIMETER CHECK (WHEN CLEARED	TO AN ALT BELOW THE TRANS LEVEL	<go around=""> OR MISSED APPROACH</go>	
ANNOUNCE	TRANSITION*ALTIMETERS XXXX,	SPEAK	GO AROUND POWER FLAPS 15
	PASSING XXXX FEETNOW*	TOGA (ONLY PRESS AFTER GA CALL)	PRESS
		PNF	POSITIVE RATE
<approach></approach>		CALL	GEAR UP
NAV RADIOS	SET	PNF CALLS	FLIGHT GUIDANCE SYSTEM SET
CALL	APPROACH CHECK	AT 1500FT	SELECT CLIMB POWER
		NORMAL CLIMB OUT FOLLOWS	

<after< th=""><th>LANDING></th><th>PARKING CHECK</th><th><pre><parking></parking></pre></th></after<>	LANDING>	PARKING CHECK	<pre><parking></parking></pre>
SPEAK	AFTER LANDING CHECK	PARKING BRAKES	SET
OR IF NO APU TO BE USED	AFTER LANDING CHECK	FLAPS / SLATS	RETRACTED
	WITHOUT APU	APU / EXT POWER	ESTABLISHED
LANDING LIGHTS/NOSE LIGHT	EXT OFF/DIM	FUEL LEVERS	OFF
		ANTI COLLISION	OFF
AFTER LANDING CHECK		HYD PUMPS	OFF
SPOILERS / ABS	RETRACTED AND OFF	SEAT BELT SW	OFF
FLAPS / SLATS	15 DEGREES TAKE OFF	ICE PROTECTION PANEL	OFF
PNEUM X-FEED	OPEN	TRANSPONDER	STANDBY
TRANSPONDER	AS REQUIRED		
RADAR	OFF	BEFORE LEAVING AIRCRAFT CHECK	<before ac="" lv=""></before>
AIR COND SUPPLY	AS REQUIRED	THIS IS A READ AND DO CHECKLIST	
APU	AS REQUIRED	EMERGENCY LIGHTS	OFF
		AIR COND	OFF
<pre><pre-shutdown></pre-shutdown></pre>		GALLEY POWER	OFF
ENTERING GATE/STAND POSITION	FLAPS AND SLATS	WINDSHILED A-ICE & A-FOG	OFF
LANDING LIGHTS/NOSE LIGHT	RET OFF/OFF	PITOT HEAT	OFF
IF APU NOT RUNNING	CONNECT EXTERNAL POWER	LIGHTS / SCREENS	OFF
	PUT EXTERNAL POWER ON BUSES	APU	OFF
FUEL LEVERS	OFF	BATTERY SWITCH	OFF
WHEN ENGINES SHUTDOWN	SEAT BELT SIGNS TO OFF		
CALL	PARKING CHECK		

** IF YOU WISH TO RUN A SECOND LEG	DO THIS AFTER COMPLETING THE
	SHUTDOWN CHECKLIST
	SKIP OVER THE PRE-START CHECKLIST
	USING ARROWS ON MAIN FS2CREW
	PANEL. CONTINUE AS NORMAL

VERSION 1.4 CREATED BY MARK WOLPERT 1-Jan-18